

### **TOP AND CABINET PARTS**

For Models: LSN1000LW1, LSN1000LG1
(White/Grey) (Risquit/Gold)

	(Whit	e/Grey) (Biscuit/Gold)
Illus. No.	Part No.	DESCRIPTION
1	LIT3956025	Literature Parts Installation Instructions
	LIT3955869 LIT3955904 LIT3956342	Use & Care Guide Feature Sheet Energy Guide
	LIT8541693	3 -3 -
		y Be Purchased
	O-IT-YOU EPAIR MA	
	LIT4313896	Manual, Washer
2	3955792	Top White
3	3955793 62750	Biscuit Spacer, Cabinet To
4 5	357213	Top (4) Nut, Push-In (2) Cabinet
-	63424 3954357	White Biscuit
6	62780	Clip, Top & Cabinet & Rear Panel (2)
7	3976348	Cabinet–Sound Damper
8	3400611	Screw, Lid Switch (2)
9	3357011	Screw, 10-16 x 1/2
10 11	8054939 8054980	
13	355274	
15	8055257	Hinge, Lid (L.H.)
16 17	8055256 19119	Hinge, Lid (R.H.) Bumper, Lid Hinge
10	0210520	Pooring Lid

18

19

22 28

31 32 8319539 Bearing, Lid Hinge (2)

Lid

3956017 Biscuit 3351614 Screw, Ground 3390631 Screw,


10–16 x 3/8 (4) 3955788 Cover, Dispenser 8519517 Dispenser, Bleach

3956016 White

### **CONTROLS AND REAR PANEL PARTS**

For Models: LSN1000LW1, LSN1000LG1 (White/Grey) (Biscuit/Gold)

IIIus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
-			15	3952821		39		Panel, Console
1	3976300	Washer, Water	'	3332021	Power Cord	39	3955844	
		Inlet Hose (4) (1–1/16 x 5/8)	16		Cap, End (L.H.)		0000044	(Includes Item 40)
2	694419		'	8271365			3955845	
2 3	094419	Hose, Water		8271368			0000010	(Includes Item 40)
3		Inlet (2)	18		Valve, Water	40	3955775	Medallion
	30/037/	Blue Coupler	'		Mixing	42		Switch, Rotary
		Red Coupler	19	303294	Edge Protector	43		Hose, Vacuum
4		Screw, Ground	20	8318201	Clip, Capacitor			Break
5		Strap, Console (2)	21		Clamp, Hose	44		Knob, Timer
6		Panel, Rear	22		Clip, Harness		8538949	(For LSN1000LW1)
7		Pad, Rear Panel			& Pressure Hose		8538952	(For LSN1000LG1)
8		Hose, Drain	23	371503	Clamp, Hose	45		Dial, Timer
Ŭ	000.000	(4 ft.)	24	387606	Break, Vacuum		8538955	(For LSN1000LW1)
	661577		25	3347812	Clip, Harness		8538956	(For LSN1000LG1)
		(9 ft.)	26	8317940	Hose, Drain	46		Knob, Control
		(Not Included)			(Anchored)		8538957	(For LSN1000LW1)
	3357090		27		Clamp, Hose			(For LSN1000LG1)
		Drain Hose	28	661605	Capacitor,	47		Clip, Knob
		(21 Inches)			Motor Start	49	388326	Screw, 8-18 x 1.25
		(Not Included)	29		Retainer, Harness			(Panel to Top)
9	8541270	Timer, Contról	30		Clamp, Hose	50	9740848	
		(60 Hz.)	31		Clamp, Hose	51		Cap, End (R.H.)
		(Motor Not A	32	3951449	Hose, Pump To Tub		8271359	
		Service Part)			(Includes #30)		8271362	
10	3351614	Screw	33		Clamp, Hose	52		Shield, Capacitor
11		Screw, 8-18 x 3/8	34		Switch, Rotary	53	3357027	Nozzle, Hose
12	3366846	Switch,	35		Screw, 10-16 x 3/8			Drain
		Water Level	36	3400818	Screw, Timer	54	3366913	Clamp, Drain
13		Bracket, Control		004044	Mounting			Hose
14	661661	Cord, Power	38	661614	Switch,	55		Shield, Suds
		(Includes Item 15)			Temperature	56	3956495	Harness, Wiring
								(For Detail See
			I					Pages 9 & 10)



# AGITATOR, BASKET AND TUB PARTS For Models: LSN1000LW1, LSN1000LG1 (White/Grey) (Biscuit/Gold)


Illus. No.	Part No.	DESCRIPTION
1 2	63580 358237	Screw & Washer
3 4 5 6	3363003 3951632 8528150 3976308	
7 8 9	3354845 3355921 3951682	Clip, Agitator Washer, Agitator
10 11	3366877 3952374	Dog, Agitator Clutch Bearing-Driven
12 13	21366 8526016	Cam
15 16 17	8519788 63849 389140	Tub
18 19	383727 3347780	Drive Gasket, Centerpost Hose, Pressure
20	3951744	Switch Agitator (Complete)
22 23 24 26	3951608 3354733 3348855 3949550	Spacer, Thrust Cap, Barrier Seal, Inner Cap Washer

## BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS For Models: LSN1000LW1, LSN1000LG1 (White/Grey) (Biscuit/Gold)

		(Whit	e/Grey) (Biscuit/Gold)			
<u>Ø</u>	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
	1	388952	Brake & Drive Tube (Complete)	10	3357334	Screw, Gearcase To Base (3)
			(Refer to Page 11 For Further	11	62611	Plate, Motor Mount To
1	2	63292	Breakdown) Washer, Spin Tube Thrust	12 13		Gearcase Grommet, Motor (4) Coupling, Motor
2	3		Ring, Spin Tube Support	15	3355454	& Isolation Clip,
3	4 5	63283	Ring, Retainer Clutch (Complete)	16	3400516	Anti–Rattle Screw
4 - 70	6		Band & Lining,	17	3349637	Retainer, Motor (2)
5.	7	60646	Clutch (Includes Illus. 7 & 8)	18		Shield, Tub To Motor
7 7	7 8		Cap, Clutch Spring (2) Spring, Clutch	19 20		Motor, Main Drive Switch, Main
	9	3360630	Gearcase			Drive Motor
			(Complete) (Refer To Page 12	21 22	62700 3363394	Retainer, Pump (2) Pump (Complete)
16			For Further Breakdown)	23 24	3387485	Screw, 10–16 x 5/8 Shield, Motor
9 10 11 12 13 24			-16 17 17 23		20	18 19 21 22 21

### **MACHINE BASE PARTS**


For Models: LSN1000LW1, LSN1000LG1 (White/Grey) (Biscuit/Gold)



Illus.	Part	
No.	No.	DESCRIPTION
1	3400076	Screw, Bracket Mounting (10–32 x 5/8)
2	64067	Bracket, Spring Outer (2)
3	63907	Spring Suspension,(3)
4	3362087	Support & Brake,
5	64065	Bracket, Spring Outer (L.F.)
6	63466	Link, Leveling Mechanism (2)
7	62597	Spring, Leveling Mechanism
8	62837	Pin, Knurled
9	62596	Foot, Rear (2)
13	3347047	Bearing,
14	257400	Centerpost (2)
15	357409 8318050	Seal, Centerpost (3) Spring,
13	0310030	Counterweight
16	62568	Pad, Plate
17	3946509	Plate, Suspension
		(Includes Illus. 16)
18	3363660	Pad, Base
19	3946512	Base Assembly
		(Includes Illus, 6,
		7, 8, 9,16,17,18,
04	2250452	& 26.)
21	3359452	Nut, Lock (3/8–16)
22	389102	Foot, Front (2)
23	356934	Seal, Centerpost (2)
24	285203	Centerpost
		Bearing Kit
		(Includes Illus.
		13, 14 & 23)
25	63134	Ring, Sound
26	62000	Deadening
20	63806	Retainer, Suspension Spring
		Cuspension opining

### **WIRING HARNESS PARTS**

For Models: LSN1000LW1, LSN1000LG1 (White/Grey) (Biscuit/Gold)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

#### **WIRING HARNESS PARTS**

For Models: LSN1000LW1, LSN1000LG1 (White/Grey) (Biscuit/Gold)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4 5 6 7 8	388498 3347812 3352501 90016 3390496	Disconnect (White)	13 14 15 16	3347243 63523 717252	Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614.) Block, Disconnect (Use Term. 352088) Protector Connector (2–Way) (Use Term.94614) Plug, Terminal (4–Way)	23 24 25 26 27	60687	Connector, Etc Connector, Relay (Use Term.308569) E.T.C. Control Connector (T.P.A.) (3-Circuit) (Lid Switch) (Use Term. 3948619 OR 3948620.) Connector (T.P.A) (3-Circuit) (Pressure Switch)
Ü	002000	Disconnect (Black)			(Power Cord) (Use M3 Screws)			(Use Term.3948619 OR 3948620.)
10	62889	Receptacle, Terminal (3–Way) (Lid Switch) (Use Term.94613) Or 94614.)	18 19 20		Clip, Harness Block, Disconnect (12–Way) (Timer) (Use Term. 94613)	28 29	3354925 3354926	Block, Connector (Cold Valve) (Use Term.693217) Block, Connector (Hot Valve)
11	353424	Plug, Terminal (3–Way) (Power Cord) (Use Term.94613)	21		(6–Way) (Use Term. 94613) Plug, Terminal (12–Way)	30	3948615	(Use Term.693217) Connector (T.P.A.) (6-Circuit) (Temp. Switch) (Use Term.3948619
12	62505		22	3369366	(Use Term. 94613 Or 94614.) Timer, Block Disconnect (Black) (Amp) (Use Term. 3369365)			OR 3948620.)

### FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

WH2G

### **BRAKE AND DRIVE TUBE PARTS**

For Models: LSN1000LW1, LSN1000LG1 (White/Grey) (Biscuit/Gold)



Illus. No.	Part No.	DESCRIPTION			
1	388952	Brake And Drive Tube (Complete)			
2	62658	Ring, Thrust			
2 3 4	91939	Seal, Oil			
4	356427	Seal, Drive Tube			
5	356937	Spacer, Drive			
		Tube			
6	64027	Tube, Basket			
		Drive (Includes			
_		Illus. 3, 4, 5 & 9)			
7	64035	Ring, Retaining			
8	64232	Shoe, Brake			
9	62703	"T" Bearing,			
10	62648	Spin Tube			
10	02040	Cap, Brake Spring (2)			
11	387806	Spring (2) Spring, Brake			
12	62909	Sleeve, Brake			
	02000	Spring			
13	63023	Cam, Brake			
		Release			
14	63022	Sleeve, Cam			
15	64194	Driver, Brake			
		Cam			
16	90368	Ring, Retaining			
	FOLLOV	VING PARTS			
NOT ILLUSTRATED					

### NOT ILLUSTRATED

285208 Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


### **GEARCASE PARTS**

For Models: LSN1000LW1, LSN1000LG1 (White/Grey) (Biscuit/Gold)

		(White/Grey) (Biscu	iil/Gola)		
r — ;	= <del></del>	- <u></u>	٦ _	1	
		,22		•	
1		\h 4 \ \rightarrow 22	l	<b>5</b> .	
1 2 <sub>1</sub>			I Illus.		
1 /	3		No.	No.	DESCRIPTION
1 1			1		
1 [			1	3360630	Gearcase (Complete)
15		23	1 2	285202	Complete) Cover, Gearcase
1 1	6	20	1 3	3349985	Seal, Gearcase Cover
; '  		7 — 24	4	285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
	8	25	5	63320	Pinion, Spin (Includes Illus. 25)
	9		6	356427	Seal, Spin Pinion
	10 -	26	7	389387	Shaft, Agitator
-	_ <b>→</b>	r — —  — <i>—</i> — — ¬	1 8	90369	(Complete) Ring, Retaining (2)
. i	9 — 👼		9	62677	Retainer, Spring
	11	<u> </u>	I 10	62676	Spring, Agitate
			J 11	63273	Gear, Agitate
	12		12	62619	(Includes 15 and 29) Washer, Agitate
;	13		1 13	62580	Gear Cam Follower
	14		14	62581	(Includes 14) Cam, Agitate
;			15	285509	(Includes 13) Shaft, Agitator
			I 16	62618	(Includes 11 and 29) Washer, Cam Thrust
-			17 1 18	16018 85529	Bearing, Thrust Ball, Bearing
;			1 19	389230	Bottom and Pinion,
1	15 _	_ 27	l 21	285352	Gearcase Seal, Thrust Plug
1			1 22	3351614	Screw, Gearcase
	16		1		Cover, Mounting (8) (10–24 x 3/8)
	16	28	23   24	3362552 285735	Ring, Retaining Washer Kit,
1	29		I 25	62570	Thrust Gear, Spin
	88		1 26	388253	Neutral Assembly
<sup>1</sup> 17 <sup>1</sup>		<u> </u>	27	3349296	Rack, Connecting
1			1 28	62621	Actuator, Shift
¦ 18			29	388815	Washer, Intermediate
i			1		memediale
		man a	1 1		
1			1		
1	21	> (	1		
I			1		
I .			I		
I .			1		
1		4	1		
I	L	GC-215-C	I		
L			J		

### **WATER SYSTEM PARTS**

For Models: LSN1000LW1, LSN1000LG1 (White/Grey) (Biscuit/Gold)




WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain
2	285321	Hose Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector,
5	285320	Straight Siphon Break Kit
6 7	65349 367031	(Not Included) Clamp, Hose Drain Protector (Not Included)

### **MISCELLANEOUS PARTS**

For Models: LSN1000LW1, LSN1000LG1 (White/Grey) (Biscuit/Gold)



Illus. No.	Part No.	DESCRIPTION
1	3976263	Miscellaneous Parts Bag
2	3976300	
3	3366912	Clamp, Hose
4		Nut, Lock (3/8–16)
5	389102	Foot, Front (2)
6		Clamp, Hose

### **OPTIONAL PARTS (NOT INCLUDED)**

Illus. Part No. No. DESCRIPT	IIIus.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	
PAINT, TOUCH-UP (1/20)	z.) PAIN	PAINT, BULK (1 qt.)		SEAL	SEALER		
72017 White 4392899 Biscuit			White (Uncut) Biscuit (Uncut)		285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)	
PAINT, PRESSURIZED SI	PRAY			ACCI	ESSOR	Y PARTS	
350938 Primer, Gray 350930 White 4392901 Biscuit	, OIL	350572	2 Oil, Gearcase (16 Oz.)			Drain Protector Siphon Break Kit	
	LUB	RICAN1	-				
		285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)				